


Parts Breakdown

Model **DI-CN-0010** 31840



Parts Breakdown

Model DI-CN-0010 31840

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
73902	Tank Cover for 31840	1-A	AK781	Button of Overheat Protector for 31840	16	73936	Cleaner Shaft for 31840	33
AP808	Knob of Tank Lid for 31840	1-B	73920	Button Stop of Protector for 31840	17	73937	Tap Handle for 31840	34
73904	Paddle for 31840	2	AK783	Tank Hinge for 31840	18	73938	Screw of Faucet for 31840	35
AL383	Lid of Stirring Rod for 31840	3-A	73922	Upper Exterior for 31840	19	73939	Pin Spring for 31840	36
73906	Stirring Rod for 31840	3-B	73923	Lower Exterior for 31840	20	73940	Pin for 31840	37
73907	PC Tank for 31840	4	AK786	Power Switch for 31840	21	73941	Lid of Water Bin for 31840	38
73908	Gasket of PC Tank for 31840	5	73925	Thermostat for 31840	22	73942	Water Bin for 31840	39
73909	Stainless Steel Boiler (Upper Part) for 31840	6	73926	Foot for 31840	23	73943	Drainage Plug for 31840	40
73910	Gasket for 31840	7	AK789	Ventilation Grill for 31840	24	73944	Lid of Water Tray for 31840	41
AK773	Overheat Protector for 31840	8	73928	Washer of Faucet (Interior) for 31840	25	27993	Float Indicator for 31840	42
AK774	Heater Element for 31840	9	73929	Nut of Faucet (Interior) for 31840	26	73946	Water Tray for 31840	43
73913	Boiler Gasket for 31840	10	76479	Gasket of Faucet for 31840	27	AK809	Forefoot for 31840	44
AK776	Electrical Stainless Steel Boiler (Lower Part) for 31840	11	73931	Nut of Faucet Exterior for 31840	28	AK810	Fan for 31840	45
73915	Supporter for 31840	12	73932	Gasket of Faucet Screw for 31840	29	73947	Supporter Off Fan for 31840	46
AK778	Motor for 31840	13	AK795	Gasket Inside the Faucet for 31840	30	AP810	Alarm Controller & Indicator Light for 31840	47
AK779	Back Cover for 31840	14	73934	Moving Pin for 31840	31	AP811	Float Switch for 31840	48
73918	Cover of Overheat Protector for 31840	15	73935	Faucet Spring for 31840	32			